

# Multi-pair Speaker Wiring Codes

revised 02/11/2005 ek/dg

## SPEAKER 4 / SS4 / EPC4



W = 1+, 1, TIP (CH 1, SPKR A)  
 K = 1-, 2, SLV (CH1, SPKR A)  
 Y = 2+, 3, TIP (CH 2, SPKR B)  
 O = 2-, 4, SLV (CH 2, SPKR B)

## SPEAKER 6 / SS6 / EPC6



W = 1+, 1      Y = 3+, 5  
 K = 1-, 2      O = 3-, 6  
 B = 2+, 3  
 N = 2-, 4

## SPEAKER 8 / SS8 / EPC8



R = 1+, 1      W = 3+, 5  
 K = 1-, 2      G = 3-, 6  
 B = 2+, 3      Y = 4+, 7  
 N = 2-, 4      O = 4-, 8

## PS-8,10,14 / POWERSNAKE-10PR, 14PR, 18PR



R = 1+, 1, TIP (CH 1, SPKR A)  
 K = 1-, 2, SLV (CH1, SPKR A)  
 W = 2+, 3, TIP (CH 2, SPKR B)  
 G = 2-, 4, SLV (CH 2, SPKR B)

## RAPCO-PS18



R = 1+, 1, TIP (CH 1, SPKR A)      B = 3+, 5, TIP (CH 3, SPKR C)  
 K = 1-, 2, SLV (CH1, SPKR A)      N = 3-, 6, SLV (CH3, SPKR C)  
 W = 2+, 3, TIP (CH 2, SPKR B)      Y = 4+, 7, TIP (CH 4, SPKR D)  
 G = 2-, 4, SLV (CH 2, SPKR B)      O = 4-, 8, SLV (CH 4, SPKR D)

R = RED  
 K = BLACK

W = WHITE  
 G = GREEN

B = BLUE  
 N = BROWN

Y = YELLOW  
 O = ORANGE